

Tube Preamp System

Two Channel Voiced Valve Preamplifier with Output Protection Limiting (OPL)

USER'S GUIDE



The ART TPSTM Tube Preamp System

TABLE OF CONTENTS

Introduction	2
Installation	3
AC Power Hookup	
Analog Audio Connections	
Safety Precautions	
Controls and Indicators	. 4
Input Control	4
+20 dB Gain Switch	
Phantom Power +48V Switch	4
Phase Reverse Switch	
V3 TM Variable Valve Voicing Control	5
VU Meter	
Output Control	
Connections	7
Dual Purpose Input Jacks (Front)	7
XLR Input Jacks (Rear)	
XLR Output Jacks (Rear)	
1/4" Output Jacks (Rear)	8
Operation	9
Warranty Information1	11
Service 1	12
TPS™ Specifications1	13

INTRODUCTION

Thank you for purchasing an ART TPSTM (Tube Preamp SystemTM) - and congratulations: You now own one of the most versatile preamplifiers available. Offering a superb level of sound quality, the TPSTM hybrid tube and solid state circuit design, combined with a straightforward user interface, quickly and easily gives you access to all of its features.

The original ART Tube MPTM put professional-caliber tube preamplification into the hands of thousands of musicians and recordists that wanted great tube tone in a compact and flexible package. The New ART TPSTM is the first tube microphone preamplification system designed with recording musicians in mind. It has been carefully designed, engineered and manufactured to provide you with years of great sound and reliable service.

The TPSTM extends the range of applications by adding **V3**TM (Variable Valve VoicingTM) which will help you to quickly and easily record a variety of instruments – including drums, keyboards, acoustic and electric guitars, and more. We also feature **OPL**TM Output Protection Limiter to make V3TM even more powerful. The TPSTM also functions as a direct box, with impedance matching and preamplification for instrument or line-level sources.

FEATURES:

- Dual Analog VU metering
- V3TM (Variable Valve VoicingTM) with OPLTM (switch selectable)
- Over 75 dB of gain
- Hand selected 12AX7A dual triode tube
- Balanced XLR inputs and outputs
- ¼" High impedance Instrument input and ¼" line level output
- +48V Phantom Power (switch selectable)
- Phase Reverse Switch
- Gain (+20dB) Switch
- Input Gain Control
- Output Level Control
- Fully shielded all-steel chassis
- Designed and developed in the USA

INSTALLATION

The TPSTM may be used in a wide variety of applications and environments. In a rack-mountable, all-steel enclosure, the units are designed for continuous professional use. Mounting location is not critical. However, for greater reliability we recommend that you not place the units on top of power amps or other sources of heat. The tube circuitry needs about a minute to "warm up" from a cold power up.

AC POWER HOOKUP

The TPSTM has an internal power supply designed to operate at 115 VAC @ 50 to 60 Hz. Units manufactured for use outside the United States of America have been modified to comply with the required electrical specifications.

ANALOG AUDIO CONNECTIONS

Audio connections to and from the TPS $^{\text{TM}}$ are balanced XLR (Pin 2 = Hot (+), Pin 3 = Cold (-), Pin 1 = Ground) and unbalanced $\frac{1}{4}$ " (Tip = Hot (+), Sleeve = Ground). We recommend that you switch off the +48V Phantom Power whenever changing connections to the XLR input. The front mounted jacks can act as both a balanced XLR connection, and an unbalanced $\frac{1}{4}$ " connection.

SAFETY PRECAUTIONS

Warning: To avoid the risk of shock or fire, do not expose this unit to moisture. Refer all servicing to qualified personnel. Do not remove the metal cover; there are no user-serviceable parts inside. When applicable, only use the power adapter that came with this unit or one obtained from ART's Customer Service Department.

CONTROLS & INDICATORS

INPUT CONTROL

The Input Control sets the amount of input gain of the TPS™. Turn the control clockwise to increase gain and counterclockwise to decrease gain. You may control two ranges of gain with this control, +20 to +68dB and +0 to +48dB. Selection of the gain range is made with the +20dB gain switch.

NOTE: This control, along with the **+20 dB Switch**, is responsible for any saturation of the tube. To change the tube character, utilize these 2 controls.

+20DB GAIN SWITCH

Use the +20dB Gain Switch to set the gain range of the input control. When the switch is out, the unit operates in Normal mode. Depressing the switch adds 20dB of gain. For microphone applications, where more gain is needed, push the switch in. For hot line level inputs, set the switch in the out position.

PHANTOM POWER +48V SWITCH

The TPSTM can power any microphone needing +48 volts DC Phantom power. Phantom power is supplied to pins 2 and 3 of the XLR Input jack when this switch is depressed. With the TPSTM, slowly apply and remove the +48 volts, to prevent damage to microphones.

Be sure to turn down or mute the output of the TPSTM when engaging or disengaging Phantom power. Additionally, when disengaging, allow 30 to 45 seconds for the power to completely discharge. Most microphones will make a sound like air leaking from a tire when Phantom power is disconnected, but some can make some very nasty low rumbles and whines as well.

Dynamic microphones should not be affected or damaged if they are plugged into a line where Phantom power is present. However, if the mic doesn't need it, do not use it. Some things are best left untested!

PHASE REVERSE SWITCH

The Phase Reverse switch is provided to reverse the phase of the signal. This switch works on Pins 2 and 3 of the XLR output jack and also reverses the polarity of the ¼" output jack. In the Normal position, the signal is in-phase. In the Reverse (or "in") position, Pins 2 and 3 are reversed and the signal is changed to 180 degrees out of phase.

In multiple microphone applications, mic placement can affect the phase of the signals. If two microphones pick up the same signal from different locations, the result can be a hollow or frequency "shifted" sound. In some cases it may sound as if an instrument disappears if it happens to be 180 degrees out of phase. Depressing the Phase switch can remedy this. In general, if your sound is "thin" or "out of position," try reversing the phase to correct the problem.

V3TM - VARIABLE VALVE VOICINGTM CONTROL

The TPSTM features ART's proprietary **V3**TM technology. V3TM (which stands for Variable Valve Voicing), provides optimized reference points to begin the recording process for guitars, bass guitars, synths, acoustic instruments, percussion and more.

ART engineers ran our preamplification circuit through a battery of tests and real life studio conditions. Our goal was to create a processor that would allow a user to have presets that were optimized for specific recording applications. We set out to create a preamp that would be nimble enough to handle both violins and kick drums, and nearly everything in between.

We wanted to take the guessing out of the equation – and that is how we developed V3. It's simple, easy and it works really well.

For example, if you are recording an acoustic guitar, V3 has a preset that has been optimized for that instrument. Once the preset is chosen, the user can even fine tune the signal – which shows the true power of V3 technology...it's tweakable. V3 even features a multi setting, which is useful for a wide variety of applications – like overhead micing, broadcast and field recording.

This means that it is now quicker and easier than ever to make great recordings! Musicians want to play, not spend hours adjusting knobs. No other microphone preamp is as user-friendly as the TPSTM.

VU METER

The VU Meter gives an analog representation of the TPSTM tube signal level. Besides showing the average analog level, it is sensitive to attack transients. When not using OPLTM, the VU Meter is a great indicator of how hard you are running the tube. It also helps in setting a consistent level as you change mics and instrument sources.

The VU Meter also reflects the impact of the OPLTM circuitry on the signal. For example, if the signal is "in the red" on the meter, the meter will reflect the attenuation of the signal when the OPLTM is activated, and the signal is brought out of the "red."

OUTPUT CONTROL

The Output Control sets the output level of the TPS™. When the control is fully counterclockwise, there is no output. Turning the control clockwise increases the level of the output signal. When setting the Output level control, refer to the VU Meter for an accurate level leaving the preamp.

CONNECTIONS

It is easy to interface the unit with a wide variety of equipment. The front panel houses 2 dual-purpose $\frac{1}{4}$ " / XLR input jacks, and the rear houses balanced XLR ins and outs as well as unbalanced $\frac{1}{4}$ " outs. Standard $\frac{1}{4}$ " and XLR inputs and outputs make patching simple.

DUAL PURPOSE INPUT JACKS (FRONT)

The front mounted dual purpose jacks act as both balanced XLR jacks, and unbalanced ¼" jacks.

The XLR Input jacks are primarily intended for microphone input, and as such can furnish Phantom Power when needed. They can handle up to +19 dBu signals, which is the hottest signal you would get out of any microphone. For even hotter input signals, you should use the ¼" input jack. The XLR Input jacks medium input impedance is extremely flat over a wide frequency range, which allows it to be musically neutral to virtually any microphone (one of the lesser known secrets – it's why the unit will always sound good!).

The ½" Input jacks are for instrument and line level inputs. They have high input impedance to minimize any loading effects on instrument pickups. They can also handle up to +22 dBu signals for line level signals.

XLR INPUT JACKS (REAR)

The rear XLR jacks function the same as the front ones, as they are directly wired together, and both cannot operate simultaneously.

If the rear XLR input and its matching front ¼" input are both in use the TPSTM will sum the two signals, with the XLR slightly attenuating the ¼" input. This is not normally suggested.

XLR OUTPUT JACKS (REAR)

The XLR Output jacks of the TPSTM are active balanced. You may use them in an unbalanced configuration without harm to the output circuitry. The XLR outputs can provide a hefty signal level (+28dBu) at a low impedance, so make sure that you do not overdrive equipment with sensitive inputs. When using it on the front end of a mixer, go into the mixer's line in or insert inputs and not necessarily into the mixer's microphone input, unless the mixer can pad that input's level.

1/4" OUTPUT JACKS (REAR)

The ¼" Output jacks are unbalanced and should be used for sending signals to amps, processors, or other unbalanced configurations.

Both balanced and unbalanced output connections may be used simultaneously. This is particularly useful when using the TPSTM as a direct box for instruments or line level signals. Make sure that both pieces of equipment connected to the preamp's outputs are connected to the same earth ground, <u>beforehand</u>, to avoid electrical shock.

If you experience a grounding hum when using both output connectors (one to a console, one to an instrument amp) simultaneously, a ground loop may be the problem. To remedy this problem, disconnect the ground wire (pin 1) from the XLR cable plugged into the preamp's output. This interrupts the ground path and therefore breaks the loop.

Fill in the following information for your reference	ence
Date of purchase	
Purchased from	
SERIAL NUMBER	

OPERATION

The TPS™ is one of the most versatile preamplification systems available. Through use of the V3™ technology, numerous instruments can be processed by the TPS™ system. Simply mic the instrument (if acoustic), amp, or plug the instrument directly in to take full advantage of V3 technology.

V3TM Settings and their applications when processing:

When observing the V3TM dial from a clockwise perspective, the following settings are:

Neutral Settings:

These are useful for uncolored, natural reproduction of sound.

6:00 - Neutral Flat

6:45 – Neutral Vocal (Microphone)

7:30 – Neutral Guitar Amplifier

8:15 - Neutral Bass Guitar

Warm Settings:

These are useful when warming a signal is desired.

9:00 - Warm Electronic Keyboard

9:45 - Warm Electric Guitar

10:30 - Warm Vocal Microphone

11:15 - Warm Valve

Warm Settings with OPL:

These are useful with high sound pressure levels, close proximity micing, and spiky transients, as well as warming the signal.

12:00 - Warm OPL Multiple Applications

12:45 - Warm OPL Vocal

1:30 - Warm OPL Acoustic Guitar

2:15 - Warm OPL Piano

Neutral Settings with OPL:

These are useful with high spl's, close micing and spiky transients, as well as maintaining clarity.

3:00 – Neutral OPL Bass Guitar

3:45 - Neutral OPL Acoustic Guitar

4:30 – Neutral OPL Percussion

5:15 – Neutral OPL Limit

Using V3TM:

The V3TM presets have been voiced with the intent of being a starting point for the recording process.

The key to good recordings is to consider all the variables you will encounter during the process.

For example...which microphone are you using? Are you recording a particularly bright guitar into a very trebly guitar amplifier? Are the strings on your acoustic made of metal or nylon? Is the room live or flat?

We mention this because V3TM is intended as a reference, not a hard-and-fast absolute. For your particular applications, a bass guitar may sound better through a non-bass preset.

If you need to, give it a twist...you'll find the setting for the tone you are searching for!

The TPSTM is also ideal for use as a DI box. Plug the instrument into either input and use the XLR or ¼" (or both) outputs to connect to your recorder, board or PA system.

Because of it's low noise and excellent tonal qualities, the TPSTM is ideal for running mixes through before recording to DAT, cassette, or even into your computer or DAW. Used as a mastering device, the preamps are capable of adding warmth and gentle tube compression to the signal. Variable Input and Output level controls make the preamps ideal for level matching material in postproduction situations.

WARRANTY INFORMATION

Limited Warranty

Applied Research and Technology will provide warranty and service for this unit in accordance with the following warrants:

Applied Research and Technology, (A R T) warrants to the original purchaser that this product and the components thereof will be free from defects in workmanship and materials for a period of **three** years from the date of purchase. Applied Research and Technology will, without charge, repair or replace, at its option, defective product or component parts upon prepaid delivery to the factory service department or authorized service center, accompanied by proof of purchase date in the form of a valid sales receipt.

Exclusions:

This warranty does not apply in the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs. This warranty is void if the serial number is altered, defaced, or removed.

A R T reserves the right to make changes in design or make additions to or improvements upon this product without any obligation to install the same on products previously manufactured.

A R T shall not be liable for any consequential damages, including without limitation damages resulting from loss of use. Some states do not allow limitations of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific rights and you may have other rights, which vary, from state to state.

For units purchased outside the United States, an authorized distributor of Applied Research and Technology will provide service.

SERVICE

The following information is provided in the unlikely event that your unit requires service.

- 1) Be sure that the unit is the cause of the problem. Check to make sure the unit has the proper power supplied, all cables are connected correctly, and the cables themselves are in working condition.
- 2) If you find the unit to be at fault, write down a complete description of the problem, including how and when the problem occurs. Please write down a description of your complete setup before calling Customer Service.
- 3) Contact our Customer Service Department at (716) 436-2720 for your Return Authorization number or questions regarding technical assistance or repairs. Customer Service hours are 9:00 AM to 5:30 PM Eastern Time, Monday through Friday.
- 4) Pack the unit in its original carton or a reasonable substitute. The packing box is not recommended as a shipping carton. Put the packaged unit in another box for shipping. Print the RA number clearly on the outside of the shipping box. Print your return shipping address on the outside of the box.
- 5) Include with your unit: a return shipping address (we cannot ship to a P.O. Box), a copy of your purchase receipt, a daytime phone number, and a description of the problem.
- 6) Ship your unit (keep your manual!) to:

APPLIED RESEARCH AND TECHNOLOGY
215 TREMONT STREET
ROCHESTER, NEW YORK 14608
RA#

TPSTM SPECIFICATIONS

1.75" H x 19" W x 6.5" D **Dimensions** Weight 5.5 lbs. **Input Connections** Front: XLR (balanced) Rear: Switchable XLR (bal.)/ 1/4" TS **Output Connections** XLR (balanced), 1/4" TS Input Impedance XLR, 1/4" 5K ohms, 1M ohm Output Impedance XLR, 1/4" 300 ohms, 150ohms Maximum Input Level, XLR +19dBu Maximum Input Level, 1/4" +22dBu Maximum Output Level, XLR +28dBu Maximum Output Level, 1/4" +22dBu **CMRR** >75dB (typical @ 1kHz) 5Hz to 50kHz, +/-.1dB Frequency Response Dynamic Range >100dB Total Harmonic Distortion (THD) <0.01% (clean), <0.1%(warm) Maximum Gain XLR to XLR 80dB 1/4" to 1/4" 68dB XLR to 1/4" 74dB 1/4" to XLR 74dB Equivalent Input Noise (EIN) XLR to XLR -129dBu (A weighted) -105dBu (A weighted) 1/4" to 1/4" 12AX7A, Dual Triode, Hand Selected Tube Type Power Requirements USA - 110-125V AC / 50hz/16W - Export units configured for country of destination.

ART maintains a policy of constant product improvement. ART reserves the right to make changes in design or make additions to or improvements upon this product without any obligation to install same on products previously manufactured. Therefore, specifications are subject to change without notice.

Applied Research & Technology

215 Tremont Street Rochester, NY 14608 USA (716) 436-2720 (716) 436-3942 (FAX) www.artproaudio.com

© 2001 Applied Research & Technology